





T60 transmitter T60TX-08*RL	
Addication areas:	Doors. entrances. gates. winches. dumds. crushers. lighting. teldhers. convevor belts. hvdraulics a.o.
Freauency:	433.92 MHz
Mod.Tyde:	FSK
Coding:	Digital pulse code
Code comb.:	Adiustable codes: 59.049 (System 460: 6.561)
	Uniaue codes: 16.777.216
Functions:	8
Output:	10 mW (by 50 ohm)
Antenna:	Built-in
* = Power subply:	T60TX-08SRL:9V exchangeable battery type:6F22 (battery change
	once a year with normal use).
	T60TX-08CRL: Rechargeable battery
	T60TX-08ERL: Rechargeable battery incl. stop button
Power consumption:	Adr. 25 mA
Charging voltage:	12-30V DC
Operating time:	Rechargeable battery: 25 hrs. continous use
Temperature:	- 20° C to +55° C (- 4° F to +131° F)
Weight:	Adr. 250 g incl. battery
Dimensions:	160 x 70 x 35 mm (6.3 x 2.76 x 1.38 in)
Protection:	IP 54
Recommended receiver:	T60 receiver and with 4 or 8 relays (fully
	compatible with system 460).

TELE RADIO AB

Sweden, Main office Tel. +46 (0)31-748 54 60 e-mail:info@tele-radio.com

www.tele-radio.com

TELE RADIO SVERIGE

Sweden Tel. +46 (0)31-724 98 00 m e-mail: sverige@tele-radio.com

> **TELE RADIO LTD** England Tel. +44 (0) 1625 509125 e-mail: england@tele-radio.com

TELE RADIO GmbH

Germanv Tel. +49 (0)94 51-944 8 550 e-mail: deutschland@tele-radio.com

TELE RADIO LLC North America & Latin America Tel. +1 (305) 459 0763 e-mail: america@tele-radio.com TELE RADIO ASIA

China Tel. +86-(0)592-3111168 e-mail: china@tele-radio.com

TELE RADIO BV Benelux Tel. +31-(0)70-419 41 20 e-mail: benelux@tele-radio.com TELE RADIO TURKEY

Turkey Tel. +90 216 574 22 94 e-mail: turkive@tele-radio.com

TELE RADIO AS Norway Tel. +47-6933 4900 e-mail: norge@tele-radio.com