



T60TX-03STx



T60TX-06STx



T60TX-08STx

<b>Midi-T Transmitter T60TX-0xSTL:</b>	
Application areas:	Winches, pumps, crushers, lighting, conveyor belts, hydraulics a.o.
Frequency:	<b>STL transmitter:</b> 433,92 MHz <b>STM transmitter:</b> 869,85 MHz
Mod. Type:	FSK
Coding:	Digital pulse code
Code comb.:	<b>STL transmitter:</b> Adjustable codes; 59.049 (System 460: 6.561) Unique codes; 16.777.216 <b>STM transmitter:</b> Unique codes; 16.777.216
Functions:	1, 2, 3, 4, 6 or 8
Output:	7 mW (by 50 ohm)
Antenna:	Built-in
Power supply:	3 Exchangeable 1,5V batteries type:AAA (battery change once a year with normal use)
Power consumption:	Apr. 20 mA
Temperature:	-20° C to +55° C
Weight:	Apr. 120 g incl. batteries
Dimensions:	113 x 66 x 35 mm (with clip)
Protection:	IP 65
Recommended receiver:	<b>STL transmitter:</b> all receivers system T60 with 433,92 MHz (fully compatible with system 460). <b>STM transmitter:</b> all receivers system T60 with 869,85 MHz

**TELE RADIO AB**

Sweden, Main office  
Tel. +46 (0)31-748 54 60  
e-mail: info@tele-radio.com

[www.tele-radio.com](http://www.tele-radio.com)

**TELE RADIO SVERIGE**

Sweden  
Tel. +46 (0)31-724 98 00  
e-mail: sverige@tele-radio.com

**TELE RADIO AS**

Norway  
Tel. +47-6933 4900  
e-mail: m.sundt@tele-radio.com

**TELE RADIO OÜ**

Estonia  
Tel. +372 44 511 55  
e-mail: m.jyrissoo@tele-radio.com

**TELE RADIO BV**

Benelux  
Tel. +31 -(0)70-419 41 20  
e-mail: info@teleradio.nl

**TELE RADIO GmbH**

Germany  
Tel. +49 (0)94 51-944 8 550  
e-mail: kontakt@tele-radio.com

**TELE RADIO LTD**

England  
Tel. +44 (0) 1625 509125  
e-mail: sales@teleradiouk.com

**TELE RADIO LLC**

North America & Latin America  
Tel. +1 305 459 0763  
e-mail: america@tele-radio.com

**TELE RADIO ASIA**

China  
Tel. +86-(0)592-5501697  
e-mail: b.sun@tele-radio.cn